

How to Guide for C-Pen Reader 2™



1

C-Pen Reader 2™ User Guide

This pen can read text for you. It is easy to use.



2

Holding the pen


Hold the pen at an angle, push down, the light comes on.



3



4



Arrow buttons give more options



Main menu, Options, Back



Choose



Menu

5

Settings

▶ Run wizard

Follow the set up instructions.

To **reset** all of the settings on the pen:



On



Settings



Run Wizard

6

Hints and Tips for You to Scan

- The pen reads best when you hold it upright.
- Make sure the light comes on. Keep pushing down gently as you scan the words.
- You can save the battery by setting up the auto-shutdown to turn off after 5 minutes.
- You can choose right- or left-handed in Settings.
- The pen can scan from right to left and left to right.
- Text Reader: choose this setting to make the pen play the words that you have scanned.
- The pen can scan and read three different languages
In Settings, select Menu Languages and choose from English, French and Spanish.
- Definitions: This setting will give you the dictionary definition of a word.
- OPD stands for *Oxford Primary Dictionary*. This gives good basic definitions of words. *Collins Dictionary* will give more complex definitions.

